



- LED Display
- Manual milking indicator
- Milk flow indicator
- Pulsation/Stimulation indicator
- Manual milking
 - Restart
 - Rinse
 - Hold button to lower all clusters for washing-optional
- Cow Selection **OR**
 - Change Stimulation
- START / STOP**
Hold button to lift all clusters at start-up - optional
- Indicator Lamp

Dematron Symbols

	Unknown Animal No.		Calendar Heat
	Cow number entered more than once this milking		High Activity
	Low Milk Alarm		High Feed Remainder
	High Conductivity		Colostrum /Antibiotic
	Illogical Milking e.g. no milk letdown		Antibiotics
	Milk Control Signal A		Dry Animal
	Milk Control Signal B		Start of Cleaning
	Backflush		Successful Cleaning

If Milking is Blocked (display shows **STOP** or **-nF-**) due for example to an animal being Dry or has Antibiotics then press the OK key to acknowledge the warning and then press the START key once more